

# **Certified Capability List**

This Capability List is based on a certification session performed by the TALQ Certification Tool (v2.6.1online.10) on 2024-12-19 04:04:28.136 +0100.

The Capability List is a consolidated list of TALQ features which are implemented in a product.

The tool has succesfully performed 60 tests.

# Product details

Product Name GreenStreet TALQ Gateway

Company Capelon AB

Type GATEWAY

Notes

**Generated on** 2024-12-19 04:04:28.136 +0100

Supported profiles

- Cabinet Control
- Lighting
- Lighting Asset Management

API version certified: 2.6.1

Certification performed by app version: 2.6.1-online.10

# **Functional tests**

The Functional Tests help customers understand the capabilities of a TALQ-certified product. All functional test cases are presented to provide comprehensive context, and successful completion of each test is indicated with a tick mark. Each Functional Test is related to a set of required TALQ

about:blank 1/28 technical test cases.

#### Configuring 5 of 11

#### Support light point control features

~

The Gateway successfully connects to a CMS and transmits its capabilities for light point control features and services.

#### Support cabinet control lighting features

The Gateway successfully connects to a CMS and transmits its capabilities for cabinet control lighting features and services.

CFG-2

#### Support sensor-based light point control features

The Gateway successfully connects to a CMS and transmits its capabilities for sensor-based light point control features and services.

CFG-3

### Discovery of the network of devices

**~** 

The Gateway transmits all its devices to the CMS together with their configuration and asset information.

CFG-4

#### Initialize light point electrical alarm thresholds

**~** 

The Gateway is able to receive the light point electrical alarm thresholds from the CMS, CFG-5 including Lamp Voltage Too High/Low, Lamp Current Too High/Low, Active Power Too High/Low and Power Factor Too Low

#### Initialize and change the cabinet control alarm thresholds

~

The Gateway is able to receive the cabinet control electrical alarm thresholds from the CMS, including < to be defined >

CFG-6

#### Initialize and change the light point parameters

**~** 

about:blank 2/28

The Gateway is able to receive the light point parameters from the CMS.

#### Initialize and change a group of luminaires

The Gateway is able to handle a command from the CMS to set or change a group of light CFG-8 points to assign them a control program.

#### Change the sampling frequency for measurements

The Gateway is able to change the sampling of measurements and properly reflected in the CFG-9 next data log sent to the CMS.

#### Change the reporting frequency for measurements

The Gateway is able to change the reporting frequency (how often it sends data logs to the CSM) for measurements.

CFG-10

#### Update the firmware of the hardware devices

The Gateway supports data package service and accepts a data package to update firmware on a physical device.

CFG-11

Monitoring 1 of 11

### Measure and report basic electrical values (Current/Voltage/Active Power/Power Factor)

MTG-1 The Gateways sends "valid values" for electrical values including mains voltage, current, active power and power factor to the CMS using one of the data logging service.

#### Measure and report cumulating energy counter

MTG-2 The Gateways sends "valid growing values" for energy counter to the CMS using one of the data logging service.

about:blank 3/28

#### Report lamps' number of operating hours

The Gateways sends "valid growing values" for lamp operating hours counter to the CMS **MTG-3** using one of the data logging service.


#### Report lamps' number of switch-on counter

The Gateways sends "valid growing values" for lamp switch-on counter to the CMS using MTG-4 one of the data logging service.

#### Report lamps' number of supply loss counter

The Gateways sends "valid growing values" for supply loss count to the CMS using one of MTG-5 the data logging service.

#### Monitor the lamp level feedback when a manual override command is sent



#### Report temperature

The Gateways sends temperature values to the CMS using one of the data logging service. MTG-8

#### Report presence detection

The Gateways sends presence detection values to the CMS using one of the data logging MTG-9 service.

#### Report noise level

The Gateways sends noise level values to the CMS using one of the data logging service. MTG-10

#### Report light level

The Gateways sends light level values to the CMS using one of the data logging service. MTG-11

about:blank 4/28

#### Report firmware updating process

The Gateway is able to report the firmware update events

MTG-12

#### Controlling 3 of 7

#### Manual control over a light point



The Gateway properly receives and handles a manual override command sent by the CMS CTR-1 for one single light point

#### Manual control over a group of light points

The Gateway properly receives and handles a manual override command sent by the CMS CTR-2 for a group of light points

#### Manual control with a delay



The Gateway properly receives and handles a manual override command that includes a delay, sent by the CMS for one single light point.

#### Manual control with a ramp



The Gateway properly receives and handles a manual override command that includes a rampup, sent by the CMS for one single light point.

#### Automatic switch light on/off based on photocell value

The Gateway can properly execute a control program that switches the light ON and OFF based on a local photocell value on a single light point.

#### Automatic change of light level when presence detected

The Gateway can properly execute a control program that changes the light dimming level based on a local presence sensor on a single light point.

about:blank 5/28

#### Automatic change of light level when noise detected

The Gateway can properly execute a control program that changes the light dimming level CTR-7 based on a local noise sensor on a single light point.

#### Alarming 3 of 5

#### Report lighting alarms to the CMS



The Gateway can produce lighting alarms and send them to the CMS using one of the data ALR-1 logger services.

#### Report electrical alarms to the CMS



The Gateway can produce electrical alarms and send them to the CMS using one of the data logger services.

ALR-2

#### Report invalid program and calendar

The Gateway can produce invalid calendar and control program alarms and send them to the CMS using one of the data logger services.

#### Report activity for sensor based lighting

The Gateway can send an event in case of activity detected and send them to the CMS using one of the data logger services.

#### Request the status of the alarm



The Gateway can report the status of the alarms as a response to a request from the CMS ALR-5

#### Programming 6 of 9

about:blank 6/28

#### Fix time switching+dimming control program that applies to all days in the year

The Gateway can receive and execute a control program that switches and dims a light point at fix time all days in the year.

# Astro-clock switching + fix time dimming control program that applies to all days in the year

The Gateway can receive and execute a control program that switches a light point at sunrise/sunset +/- few minutes and dim it during an astro-clock active period, all days in the year.

# Photocell switching + fix time dimming control program that applies to all days in the year

The Gateway can receive and execute a control program that switches a light point when photocell indicates darkness and dim it during the photocell active period, all days in the year.

# Photocell and astro-clock switching + fix time dimming control program that applies to all days in the year

The Gateway can receive and execute a control program that switches a light point when photocell indicates darkness or at sunrise/sunset +:- few minutes (the earlier for switch ON/OFF) and dim it during the photocell active period, all days in the year.

#### Part night switching program

The Gateway can receive and execute a control program that switches a light point OFF at **PRG-5** fixed time in the middle of the night.

#### Support exceptional periods (e.g., Sept 10th to Oct 16th)

The Gateway can receive and execute a calendar that has a default rule for all days in the year and another higher priority calendar that applies from DAY 1 to DAY 2.

#### Support exceptional week days (e.g., every Saturday and Sunday)

The Gateway can receive and execute a calendar that has a default rule for all days in the year and another higher priority calendar that applies every Saturday night and Sunday night, every day in the year.

about:blank 7/23

Support exceptional week days (e.g., every Saturday and Sunday) and exceptional periods (e.g., Sept 10th to Oct 16th)

The Gateway can receive and execute a calendar that has a default rule for all days in the year, another higher priority calendar that applies every Saturday night and Sunday night, every day in the year and another higher priority calendar that applies to every saturday between DAY 1 and DAY 2.

#### Support dynamic lighting program based on sensor detection

The Gateway can receive and execute a control program that has rule based on presence PRG-9 sensor.

# Capability list

# **Security**

Enabled <

# **Functions**

#### **Basic**

The Basic function describes the properties related to the physical asset to which the logical device is associated, such as identification (assetId) and location information.

#### **Attributes**

# Attribute	Description
✓ swVersion	Software version installed on the device.
✓ installationDate	The installation date of Physical Device.

about:blank 8/28

✓ location	Latitude, Longitude and Altitude. [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new LocationSensorFunction.location instead.]
✓ currentTime	Current time of the device defined as local time with time zone designator. [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new TimeFunction.currentTime instead.]
•	

✓ operatingHours Number of operating hours of the device.

#### **Events**

# Event type	Description
✓ deviceReset	The physical device containing the logical device was reset
✓ cabinetDoorOpen	Cabinet door is open. [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new SegmentMonitor.cabinetDoorOpen instead.]

#### Communication

The Communication Function contains attributes related to the communication within the ODN, and between ODN devices and Gateways. Although communication within the ODN is outside the scope of the TALQ Smart City Protocol, this Function enables access to a minimum set of configuration and state information of the ODN communication interface in order to facilitate system management from the CMS.

#### **Attributes**

#	Attribute	Description
~	physicalAddress	Physical address of the device. For example, IEEE MAC address. This attribute can be used to map between logical and physical devices. The format is specific to the ODN implementation.

#### **Events**

#	Event type	Description
<b>✓</b>	communicationFailure	This event is generated by the ODN when the communication function is not operating as expected

about:blank 9/28

#### Gateway

The Gateway function includes the necessary attributes to enable the communication between the CMS and the Gateway according to the TALQ Specification.

#### **Attributes**

#	Attribute	Description
<b>~</b>	cmsUri	Base URI for TALQ communication that allows the Gateway to access the CMS. Must be an absolute URI. Other URI's for accessing CMS can be relative to this base.
<b>~</b>	cmsAddress	CMS UUID address
<b>~</b>	gatewayUri	Base URI for TALQ communication that allows the CMS to access the Gateway. Must be an absolute URI. Other URI's for accessing Gateway can be relative to this base.
<b>~</b>	gatewayAddress	Gateway UUID address
<b>✓</b>	retryPeriod	Time duration before the Gateway retransmits a message for which expected response has not been received. [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new GatewayFunction.gatewayRetryPeriod instead.]
<b>~</b>	gatewayRetryPeriod	Time duration before the Gateway retransmits a message for which the expected response has not been received. This attribute can be used by the CMS to avoid requests overload. Although this attribute will be mandatory for Gateway in future MAJOR versions, to keep backward compatibility it is considered optional for the existing profiles.
<b>~</b>	gatewayNumberOfRetries	Maximum number of retries for a failed request sent be the Gateway for which expected response has not been received. Default value shall be 3. This attribute can be used by the CMS to avoid requests overload. Although this attribute will be mandatory for Gateway in future MAJOR versions, to keep backward compatibility it is considered optional for the existing profiles.
<b>~</b>	crlUrn	URI where the Gateway can obtain the Certification Revocation List (CRL).
	vendor	Vendor identification.

about:blank 10/28

#### **Lamp Actuator**

The Lamp Actuator function includes attributes related to lighting control and it represents the smallest unit for control purposes. In practice, however, a Lamp Actuator function can control combinations of several lamps and control gear but all in the same way, as if they are all one individual unit.

#### **Attributes**

# Attribute	Description
✓ defaultLightState	Sets the default light output for the lamp actuator. This shall be applicable if no other command is active. This attribute shall be set to 100% as default value.
✓ targetLightCommand	Latest command for the lamp actuator.
✓ feedbackLightCommand	This attribute reflects the command in effect and it might deviate from the actualLightState due to propagation time or due to internal ODN specific mechanisms to handle the priority of the requests.
✓ actualLightState	This attribute should reflect the physical state of the light source as much as possible, including factors such as CLO. It may be calculated or measured, depending on the specific ODN implementation, which is outside the scope of this specification.
✓ calendarID	TALQ Address of the calendar controlling this lamp actuator. If this attribute is empty, the behavior shall be determined by the ODN. If the attribute is invalid, the ODN shall trigger a generic invalid address event and the behavior shall be determined by the ODN.

#### **Events**

#	Event type	Description
<b>~</b>	lightStateChange	Light state has changed

#### **Lamp Monitor**

The Lamp Monitor function enables monitoring of lamp parameters. A Lamp Monitor function should be associated with a specific lamp/control gear combination. Multiple lamp monitor functions may be implemented by a single device.

#### **Attributes**

about:blank 11/28

#	Attribute	Descri	ntion
π . •			•
	actuatorReference	whose	on ID of the actuator, located in the same device, effect is being monitored by this function. e.g.:  ActuatorId_1 or fGenericActuatorId_2
<b>~</b>	operatingHours		er of hours the lamp is on. This is the value used in CLC ay be set by the CMS.
<b>~</b>	temperature	[DEPRI	rature of the device implementing this function. ECATED: This attribute has been deprecated and it will oved in the next MAJOR release. Please use the new ratureSensorFunction.temperature instead.]
<b>~</b>	supplyVoltage		upply volts when supplyType is AC, supply voltage (V) supplyType is DC.
<b>~</b>	supplyCurrent		upply current (A) when supplyType is AC, supply (A) when supplyType is DC.
<b>~</b>	activePower	Active	power.
<b>~</b>	reactivePower	Reactiv	ve power.
<b>~</b>	apparentPower	Appare	ent Power.
<b>~</b>	powerFactor	Active	power/Apparent power.
<b>~</b>	activeEnergy	Cumula	ative active energy (since installation or counter reset).
=V6 #	ents Event type		Description
π			•
•	lampFailure	:	The lamp is not operating as it is supposed to (e.g. the lamp is broken). This event shall be used to detect a situation where the lamp (or LED module(s)) should be lit, but produce no light. This could be detected by the current flowing or power consumed.
<b>~</b>	dimmingFailure		The lamp is not dimming as it is supposed to (e.g. the driver is not connected properly). This event shall be
			used to detect a situation where the lamp (or LED module(s)) is lighting at a dimming level which is different from the expected dimming level, taking into account the programmed (or manual) level as well any correction (e.g. virtual power, constant light output).

about:blank 12/28

### **Electrical Meter**

The electrical meter function supports electrical metering capabilities including measurements of voltage, current, power, energy, and power factor. This function may be associated with Luminaire Controllers, Cabinet Controllers or electrical meters installed in switch boxes. ODNs may implement both single phase and three phase meters. Typically meters within a control device will be single phase and stand-alone meters. A street side cabinet may have single phase or three phase meters.

#### **Attributes**

# Attrib	ute	Description
✓ totalPo	ower	Sum of the active power consumed on phase 1, 2 and 3, or just the power for a single phase meter.
✓ totalVA	4	Sum of the apparent power consumed on phase 1, 2 and 3, or just the apparent power for a single phase meter.
✓ totalVA	<b>λ</b> R	Sum of the reactive power consumed on phase 1, 2 and 3, or just the reactive power for a single phase meter.
✓ totalAd	ctiveEnergy	Total cumulative kWh measured by the meter since installation date (or counter reset).
✓ totalRe	eactiveEnergy	Total cumulative kVArh measured by the meter since installation date (or counter reset).
✓ totalAp	oparentEnergy	Total cumulative kVAh measured by the meter since installation date (or counter reset).
freque	ncy	Frequency on the line.
✓ totalPo	owerFactor	Total active power divided by total apparent power.
✓ phase	1PowerFactor	Power factor on phase 1.
✓ phase	2PowerFactor	Power factor on phase 2.
✓ phase	3PowerFactor	Power factor on phase 3.
<b>✓</b> supply	Voltage	Average between Phase1 RMS Voltage, Phase2 RMS Voltage and Phase3 RMS Voltage, or in the case of a single phase meter just the RMS supply voltage.
✓ phase	1Voltage	RMS Voltage between phase 1 and neutral.
✓ phase	2Voltage	RMS Voltage between phase 2 and neutral.
✓ phase	3Voltage	RMS Voltage between phase 3 and neutral.
✓ totalCi	urrent	Sum of the RMS currents on phase 1, 2 and 3.
✓ phase	1Current	RMS current on phase 1.
	2Current	RMS current on phase 2.

about:blank 13/28

✓ phase3Current	RMS current on phase 3.
✓ phase1ActivePower	Active Power on phase 1.
✓ phase2ActivePower	Active Power on phase 2.
✓ phase3ActivePower	Active Power on phase 3.
✓ phase1ReactivePower	Reactive Power on phase 1.
✓ phase2ReactivePower	Reactive Power on phase 2.

✓ phase3ReactivePower Reactive Power on phase 3.

#### **Events**

#	Event type	Description
<b>~</b>	phase1ActivePowerTooHigh	Indicates the phase 1 active power is above the phase1ActivePowerHighThreshold
<b>~</b>	phase1ActivePowerTooLow	Indicates the phase 1 active power is below the phase1ActivePowerLowThreshold
<b>~</b>	phase2ActivePowerTooHigh	Indicates the phase 2 active power is above the phase2ActivePowerHighThreshold
<b>~</b>	phase2ActivePowerTooLow	Indicates the phase 2 active power is below the phase2ActivePowerLowThreshold
<b>~</b>	phase3ActivePowerTooHigh	Indicates the phase 3 active power is above the phase3ActivePowerHighThreshold
<b>~</b>	phase3ActivePowerTooLow	Indicates the phase 1 active power is below the phase2ActivePowerLowThreshold

## **Light Sensor**

A Light Sensor function models the output of light sensor. This function is optional for both CMS and Gateway, but when supported the requirements in this section shall apply.

#### **Attributes**

#	Attribute	Description
<b>✓</b>	lightLevel	Illuminance level.

### **Events**

# Event type	Description
✓ levelTooHigh	Indicates the light level is above the levelHighThreshold
✓ levelTooLow	Indicates the light level is below the levelLowThreshold

about:blank 14/28

#### **Generic Actuator**

The Generic Actuator function includes attributes related to generic control and it represents the smallest unit for control purposes.

#### **Attributes**

#	Attribute	Description
<b>~</b>	defaultState	Sets the default state output for the generic actuator. This shall be applicable if no other command is active.
<b>~</b>	actualState	This attribute should reflect the physical state of the source as much as possible. It may be calculated or measured, depending on the specific ODN implementation, which is outside the scope of this specification.
<b>~</b>	targetCommand	Latest command for the generic actuator.
<b>~</b>	feedbackCommand	This attribute reflects the command in effect and it might deviate from the actualState due to propagation time or due to internal ODN specific mechanisms to handle the priority of the requests.
<b>~</b>	calendarID	TALQ Address of the calendar controlling this generic actuator. If this attribute is empty, the behavior shall be determined by the ODN. If the attribute is invalid, the ODN shall trigger a generic invalid address event and the behavior shall be determined by the ODN.

#### **Events**

#	Event type	Description
<b>✓</b>	stateChange	The state has changed.

# Segment Monitor<sup>★</sup>

The Segment Monitor function enables monitoring of segment parameters. Multiple segment monitor functions may be implemented by a single device.

#### **Attributes**

#	Attribute	Description
<b>~</b>	segmentReference	Reference of the segment monitor depending on the use
		case. E.g.: "Segment A1"

about:blank

<b>~</b>	actuatorReference	Function ID of the actuator, located in the same device, whose effect is being monitored by this function. e.g.: fLampActuatorId_1 or fGenericActuatorId_2
<b>✓</b>	localOverride	Indicates that there is a local override (ON, OFF) or no override
<b>✓</b>	actualState	This attribute should reflect the physical relay state (ON, OFF) of the source as much as possible. It may be calculated or measured, depending on the specific ODN implementation, which is outside the scope of this specification.

#### **Events**

#	Event type	Description
<b>~</b>	circuitBreakerTripped	Indicates that the circuit breaker has tripped

#### **Luminaire Asset**

This entity contains the managed and tracked attributes of a specific Luminaire, excluding the concept of Controller and Driver.

#### **Attributes**

#	Attribute	Description
<b>~</b>	luminaireTypeAddress	Address of the Luminaire Type
<b>~</b>	bracketTypeAddress	Address of the Bracket Type
<b>~</b>	serial	Serial number of the Luminaire
<b>~</b>	projectID	Name of the Project / Tender
<b>~</b>	luminousFluxConfiguration	Programmed light output of the luminaire
<b>~</b>	paintingColor	Painting color of the luminaire expressed as a color system-color value, (e.g: RAL-7035)
<b>~</b>	virtualPowerOutput	Percentage of nominal power at which the light source should be set when the Command is set to 100%.
<b>~</b>	installationTimestamp	Installation date and time of luminaire
<b>~</b>	identification	Luminaire identification. (e.g: as per DiiA/D4i specification part 251 (MB1 extension)).
<b>~</b>	identificationNumber	Luminaire identification number. (e.g: as per DiiA/D4i specification part 251 (MB1 extension))
<b>~</b>	mountingOption	Installed direction of the luminaire to the support

about:blank 16/28

✓ warrantyExpirationDate	Warranty expiration date. It can be reset
✓ manufactureYear	Year of manufacture of the luminaire.
✓ manufactureWeek	Week of manufacture of the luminaire.
✓ warrantyYears	Number of years for warranty
✓ applicationType	Application Type of the luminaire asset depending on the use case.

#### **Driver Asset**

This entity contains the managed and tracked attributes of a specific driver

#### **Attributes**

#	Attribute	Description
<b>~</b>	driverTypeAddress	Address of the Driver Type
<b>~</b>	serial	Serial number of the driver
<b>~</b>	projectID	Name of the Project / Tender
<b>~</b>	firmwareVersion	Version of the driver hardware firmware
<b>~</b>	installationTimestamp	Installation date and time of driver
<b>~</b>	manufactureYear	Year of manufacture of the driver
<b>~</b>	manufactureWeek	Week of manufacture of the driver.
<b>~</b>	warrantyExpirationDate	Warranty expiration date. It can be reset
<b>~</b>	applicationType	Application Type of the driver asset depending on the use case.

#### **Controller Asset**

This entity contains the managed and tracked attributes of a specific controller

#### **Attributes**

# Attribute	Description
controllerTypeAddress	Address of the Controller Type
✓ serial	Serial number of the Controller
✓ firmwareVersion	Version of the controller hardware firmware
✓ installationTimestamp	Installation date and time of OLC

about:blank 17/28

✓ registrationTimestamp	Registration date and time of OLC
✓ projectID	Name of the Project / Tender
✓ controllerColor	Painting color of the controller expressed as a color system-color value, (e.g: RAL-7035)
connectionType	Type of the connection to the luminaire
✓ warrantyExpirationDate	Warranty expiration date. It can be reset
✓ manufactureYear	Year of manufacture of the controller
✓ manufactureWeek	Week of manufacture of the controller
✓ applicationType	Application Type of the controller asset depending on the use case.

#### **Cabinet Configuration**

The Cabinet Configuration function defines attributes and functionality needed to control light from a street light cabinet regarding the segment monitors

#### **Attributes**

#	Attribute	Description
<b>~</b>	actuatingType	Actuating Type of the cabinet actuator depending on the use case. E.g.: "DALI, Relay Control"

#### **Cabinet Monitor**

The Cabinet Monitor function defines attributes for monitoring a street light cabinet

#### **Attributes**

#	Attribute	Description
<b>~</b>	cabinetDoorOpen	Indicates that the cabinet door is open.

# **Services**

# **Configuration Service**

The TALQ Configuration Service enables discovery and configuration of devices and services

about:blank

# **Options**

#	Option	Value	Description
<b>~</b>	commissioningSupported*		This ODN can support commissioning from the CMS side.
<b>~</b>	devicesPaginationSupported*		This ODN can support pagination of devices.

#### **Control Service**

The Control service describes the mechanisms to operate the actuator functions in order to enable schedule based and override control

# **Options**

#	Option	Value	Description
<b>✓</b>	supportedTypes	<ul> <li>AbsoluteActivePeriod</li> <li>AstroClockActivePeriod</li> <li>ccDate*</li> <li>ccDay*</li> </ul>	Control Program and calendar options supported are defined by announcing supported for the given modes
<b>~</b>	maximumCalendars		Maximum number of calendars supported
<b>~</b>	maximumPrograms		Maximum number of control programs supported
<b>~</b>	dayOffset	• 1 • 2	Offset of start of day
<b>~</b>	ccDateSupport	<ul><li>f</li><li>u</li><li>I</li><li>I</li></ul>	Indicates the ccDate options supported
<b>~</b>	ccDaySupport	• f • u • I • I	Indicates the ccDay options supported

about:blank

<b>~</b>	programSecondsSupported*	Indicates whether
		the field of seconds
		is supported in
		programs.

#### **Events**

#	<b>Event Type</b>	Description
<b>~</b>	invalidCalendar	An invalid calendar has been provided by the CMS to the ODN
<b>~</b>	invalidProgram	A control program has been provided by the CMS, which cannot be implemented by the ODN

#### **Data Collection Service**

The TALQ Data Collection Service is a provision to configure how ODN measurements, status information and events are logged, and when or under what conditions the logged data is transferred to the CMS

#### **Options**

#	Option	Value	Description
<b>~</b>	supportedModes	<ul><li>ImmediateReportingMode</li><li>VendorRecordingMode</li><li>EventRecordingMode</li></ul>	Recording and Reporting modes supported

#### **Events**

#	<b>Event Type</b>	Description
<b>~</b>	invalidLoggerConfig	The CMS has provided a data logger configuration that cannot be implemented by the ODN

#### On Demand Data Request Service

This service provides the mechanism to access attributes in the logical devices by requesting attribute values from the ODN

#### **Asset Management Service**

The TALQ Asset Management Service provides a mechanism to transfer the types needed by the asset management functions

about:blank 20/28

# **Objects**

## **Luminaire Type**

The LuminaireType consists of a set of attributes that together characterize, i.e.: are generic for, a given luminaire, excluding the concept of Controller, Driver and Bracket.

## **Properties**

# Property	Description
✓ address	TALQ address of the Luminaire Type
✓ name	Descriptive name of the LuminaireType
✓ gtin	Global Trade Item Number of luminaire
✓ manufacturerName	Name of manufacturer
✓ productFamily	Product family name of luminaire
✓ model	Product model of luminaire
✓ hardwareVersion	Hardware version
✓ maximumLuminousFluxOutput	Maximum Light Output luminous flux output
✓ minimumLuminousFluxOutput	Minimum Light Output of the luminaire
✓ lightSourceType	Light source type.
✓ lightDistributionType	Enumeration of possible light distribution type, using the Zhaga D4i enumeration. Please refer to ZD4i standard for more details.
✓ IcsRating	Defines the distribution of light within in three primary solid angles. (LCS: Luminaire Classification System for outdoor luminaires for TM 15 - 11 standard.). E.g: F6-33-19-1, B6-26-10-1, U0-0.
✓ lightPhotometry	Reference to the photometry of the manufacturer. IES LDT file (e.g. DN08)
✓ driverReplaceable	Informs if the driver is replaceable with values: On site, Workshop, No replaceable

about:blank 21/28

✓ lightSourceReplaceable	Informs if the light source is replaceable with values: On site, Workshop and No replaceable
✓ corrosionClass	Extra protection layer against corrosition environment. To use standard ISO 9223 C1 to C5 (https://www.iso.org/standard/53499.html)
✓ maximumPower	Maximum power that the Luminaire can operate at
✓ powerConsumption	Expected Power consumption of the luminaire
✓ powerAtMinimumDimLevel	Power at minimum dim level for the luminaire.
✓ weight	Weight of the luminaire
✓ aerodynamicResistance	Equivalent surface area of the luminaire that is exposed to the wind at 0 degrees inclination. m2.
✓ materialEnclosure	Material of enclousure of the body of the luminaire
✓ materialLlightCover	Material of light cover [DEPRECATED: This attribute has been deprecated and it will be removed in the next MAJOR release. Please use the new materialLightCover instead.]
✓ materialLightCover	Material of light cover
✓ lightCoverShape	Shape of the luminaire cover
✓ luminaireEfficacy	Efficacy of the luminaire
✓ socketTypes	List of socket pairs types/receptacles and positions of the luminaire. E.g: [NEMA at top, Zhaga at underside and Other at remote]
✓ controlVoltMax	DC voltage that gives the maximum light output in a 1-10V control type.
✓ controlVoltMin	DC voltage that gives the minimum light output in a 1-10V control type.
✓ minLightOutput	Sets the minimum light output under which the lamp actuator will not perform the command.

about:blank 22/28

✓ virtualLightOutput	Sets the light output that the lamp actuator shall consider to be equal to 100%. This scaling factor shall be applied before applying the required control voltage. The light command output shall be scaled using this factors, so that 100% in the light command corresponds to this value before applying CLO and maintenance factors.
✓ daliLedLinear	If set to True indicates the dimming curve is linear for DALI control type (some lamp control gear only use linear).
✓ warmUpTime	Sets the delay after a Switch ON command during which the lamp actuator shall not perform any dimming command.
✓ coolDownTime	Sets the delay after a Switch OFF command during which the lamp actuator shall not perform any Switch ON command.(seconds)
✓ maxOperatingHours	Maximum number of operating hours that the lamp is supposed to live with a given specification. This attribute can be used to set the old lamp attributes when the lamp reaches its expected useful life.
✓ powerLightGradient	The ratio of change of light level divided by change in power level, which is the slope of the Light level vs. Power curve. It is assumed that 100% power refers to 100% light output. If this attribute is not specified, the attribute shall be set to 1 as default.
✓ lampPowerTolerance	The number of watts by which the actual lamp power can be in error from the expected lamp power (as defined by the dimming curve and the current dimming level) before a lamp power event (lampPowerTooHigh or lampPowerTooLow) is triggered.

about:blank 23/28

✓ IumenDepreciationCurve	Ordered set of entries (cumulative operating hours, correction factor in %) that form a piece wise linear approximation of the lumen depreciation correction factor curve. The first cumulative hours should be 0 and the last correction factor should be 100%. E.g.: 0 h, 80%; 5000 h, 85%; 10000 h, 90%; 15000 h, 95%; 20000 h, 100%.
<b>✓</b> cloType	Determines where CLO (Constant Lumen Output) is implemented in the lamp control gear or in the ODN (e.g. control device). This CLO profile is needed even when CLO is implemented by the driver in order to obtain the expected lamp power.
✓ powerFactorThresholdDimmingCurve	Ordered set of entries (power factor threshold, dim level in %) that form a linear approximation of the power factor threshold vs dimming curve. The first dimming should be 0% and the last 100%. E.g.: 0.65, 0%; 0.60, 10%; 0.70, 20%; 0.75, 30%; 0.80, 40%; 0.85, 50%; 0.87, 60%; 0.89, 70%; 0.90, 80%; 0.95, 90%; 0.98, 100%.
✓ warrantyYears	Number of years for warranty
✓ lightSourceLedCurrent	LED board current
✓ lightSourceLedVoltage	LED board voltage
✓ lightSourceLedNumber	Number of LEDs
✓ lightSourceGtin	Global Trade Item Number of light source
✓ lightSourceManufacturerName	Name of light source manufacturer
✓ lightSourceProductFamily	Product family name
✓ lightSourceModel	Light source model
✓ lightSourceLedEficacy	Efficacy of the LED
✓ minimumOperatingTemperature	Minimum environment temperature in which the luminaire can operate
✓ maximumOperatingTemperature	Maximum environment temperature in which the luminaire can operate
✓ commonModeOverVoltageProtection	Common mode over voltage protection

about:blank 24/28

<b>~</b>	diferentialModeOverVoltageProtection	Diferential mode over voltage protection
<b>~</b>	electricalIsolationClass	Electrical Isolation class.

## **Bracket Type**

The BracketType consists of a set of attributes that together characterize, i.e: are generic for, a given Bracket.

# **Properties**

#	Property	Description
<b>~</b>	address	TALQ address of the Bracket Type
<b>~</b>	name	Descriptive name of the Bracket Type
<b>~</b>	gtin	Global Trade Item Number of bracket
<b>~</b>	manufacturerName	Name of manufacturer
<b>~</b>	productFamily	Product family name of bracket
<b>~</b>	model	Product model of bracket
<b>~</b>	mountingOptions	Different options to mount the luminaire to the support
<b>~</b>	mountMinDiameter	Mount minimum diameter of the bracket
<b>~</b>	mountMaxDiameter	Mount maximum diameter of the bracket
<b>~</b>	tiltMinimum	Minimum horizontal inclination of the bracket (positive and negative value). 0 degree means that it is parallel to the LED board
<b>~</b>	tiltMaximum	Maximum horizontal inclination of the bracket (only positive value). 0 degree means that it is parallel to the LED board
<b>~</b>	weight	Weight of the bracket
<b>~</b>	aerodynamicResistance	Equivalent surface area of the bracket that is exposed to the wind. m2.

# **Driver Type**

The DriverType consists of a set of attributes that together characterize, i.e. are generic for, a given Driver.

# **Properties**

#	Property	Description
"	1 Topolty	Besonption

about:blank 25/28

<b>~</b>	address	TALQ address of the Driver Type
<b>~</b>	name	Descriptive name of the Driver Type
<b>~</b>	controlElectricalInterfaceTypes	The control electrical interface type of the connector of the driver
<b>✓</b>	controlInterfaceProtocolTypes	The control interface protocol type of the connector of the driver.
<b>~</b>	programInterfaceType	Program interface of the driver
<b>✓</b>	nominalAcMainsVoltage	Nominal AC mains voltage for the luminaire to operate.
<b>~</b>	maxAcMainsVoltage	Max AC mains voltage for the luminaire to operate.
<b>~</b>	minAcMainsVoltage	Nominal Min AC mains voltage for the luminaire to operate.
<b>✓</b>	nominalDcMainsVoltage	Nominal DC mains voltage for the luminaire to operate.
<b>~</b>	maxDcMainsVoltage	Max DC mains voltage for the luminaire to operate.
<b>✓</b>	minDcMainsVoltage	Nominal Min DC mains voltage for the luminaire to operate.
<b>~</b>	gtin	Global Trade Item Number of driver
<b>~</b>	manufacturerName	Name of driveer manufacturer
<b>~</b>	productFamily	Product family name
<b>~</b>	model	Driver model
<b>~</b>	hardwareVersion	talq. feature. property. Driver Type. hardware Version. desc
<b>~</b>	minOutputCurrent	Min output current
<b>~</b>	maxOutputCurrent	Max output current
<b>~</b>	minOutputVoltage	Min output voltage
<b>~</b>	maxOutputVoltage	Max output voltage
<b>~</b>	controlOutputType	Constant voltage or constant current regulated
<b>~</b>	dimmingOutputType	Dimming output type
<b>~</b>	dimmingOutputs	Number of dimming outputs
<b>✓</b>	driverNominalCurrent	The pre-programmed current in the driver, determined also by the LED board
<b>~</b>	driverNominalVoltage	The pre-programmed voltage in the driver, determined also by the LED board

about:blank 26/28

✓ ratedLifeTime	Rated life time of the driver at the maximum operating temperature of the luminaire.
✓ warrantyYears	Number of years for warranty

## **Controller Type**

The ControllerType consists of a set of attributes that together characterize, i.e. are generic for, a given Controller.

# **Properties**

#	Property	Description
<b>~</b>	address	TALQ address of the Controller Type
<b>~</b>	name	Descriptive name of the Controller Type
<b>~</b>	gtin	Global Trade Item Number of the controller
<b>~</b>	powerConsumption	Expected Power consumption of the controller
<b>~</b>	locationPrecision	Accuracy of the location determination
<b>~</b>	manufacturerName	Name of manufacturer
<b>~</b>	productFamily	Product family name of the controller
<b>~</b>	model	Model of the Controller
<b>~</b>	warrantyYears	Number of years for warranty
<b>~</b>	mechanicalInterfaces	Type of mechanical connection or socket
<b>~</b>	electricalInterfaces	The control interface protocol type of the connector of the driver.
<b>~</b>	protocols	Type of digital communication of the controller

## Event log data

Event log data contains a single event, with eventType and value, in each single log entry. It also includes information about whether the log denotes the start or end of the event. Furthermore additional information can be added with the info attribute.

# **Properties**

#	Property	Description
<b>~</b>	eventType	Identifier of event reported
<b>~</b>	srcAddress	Address of Logical device or function within a logical device which is the source of the event or to which this event applies

about:blank 27/28

#### Command


A command defines a type of control action that can be applied to a function. Commands can be generated by a manual override action or by a control program.

#### **Properties**

#	Property	Description
<b>~</b>	state	Light state to be applied to the lamp actuator
<b>✓</b>	cmsRefld	CMS reference, which can be used for data logging. The cmsRefld in a Command is a free text to be used by the CMS for any purpose, e.g: to differentiate contexts. It is a token that allows the CMS to match client requests to the original notification.
~	expiration	Time when the control action resulting from command shall be terminated. This attribute is used only with override commands to set a time to stop an override action. After the expiration of an override command, the system should go back to the state defined by the active control program. If not specified, there is no expiration for the override command.

★: The Certification Test Tool is designed to provide a high level of confidence that complementary systems can communicate successfully. As both the protocol and the test tool evolve, all mandatory and other core tests are confirmed by comparison with real-life scenarios (plug-fest or similar). Some tests of optional and more peripheral features may not yet have been confirmed in this way; such features are identified with an asterisk (\*).

This Capability List is based on a certification session performed by the TALQ Certification Tool (v2.6.1-online.10) on 2024-12-19 04:04:28.136 +0100.



G TALQ Consortium



about:blank 28/28